

tyco
Electronics



Elo Entuitive Touchmonitor User Guide

For 19" LCD Modular Kiosk Touchmonitors
1947L Series

entuitive
Technologies



Revision B

Elo Entuitive Touchmonitor User Guide

19" LCD Kiosk Touchmonitor

1947L Series



Revision B

P/N 008581

Elo TouchSystems, Inc.

1-800-ELOTOUCH
www.elotouch.com



Table of Contents

Chapter 1		
Introduction	1	
Precautions	1	
About the Product	1	
Chapter 2		
Installation and Setup	3	
Unpacking Your Touchmonitor	3	
Product Overview	4	
Main Unit	4	
Rear View	4	
Bottom View	5	
Attaching the L-Brackets	5	
Panel Cut Outs	6	
Mounting Options	6	
Horizontal Mount	7	
Vertical Mount	8	
Horizontal Side Mount	9	
Vertical Side Mount	9	
Touch Interface Connection	10	
Serial or USB Connection	10	
STEP 1-Connecting the Video Cable	11	
STEP 2-Connecting the Serial/USB Touchscreen Cable	12	
Step 3-Connecting the OSD Remote Cable	13	
STEP 4-Connecting the Power Cable	14	
Optimizing the LCD Display	15	
VESA Mount on Your Touchmonitor	15	
VESA Mounting Interface	16	
Installing the Driver Software	17	
Installing the Serial Touch Driver	18	
Installing the Serial Touch Driver for Windows XP, Windows 2000, Me, 95/98 and NT 4.0	18	
Installing the Serial Touch Driver for MS-DOS and Windows 3.1	19	
Installing the USB Touch Driver	20	
Installing the USB Touch Driver for Windows XP, Windows 2000, Me and 98	20	
Chapter 3		
Operation	21	
About Touchmonitor Adjustments	21	
Using the On-Screen Display (OSD) Menus	21	
Remote OSD Buttons	22	
OSD Menu Function	23	
Chapter 4		
Troubleshooting	25	
Solutions to Common Problems	25	
Appendix A		
Appendix B		
Care and Handling of Your Touchmonitor	30	
Appendix C		
Compatible Video Modes	31	
19" LCD Touchmonitor (ET1947L-XXWC-1) Specifications	32	
IntelliTouch Touchmonitor Specifications	33	
AccuTouch Touchmonitor Specifications	35	
19" LCD Touchmonitor (ET1947L-XXWA-1) Dimensions	36	
Front Dimensions	36	
Rear Dimensions	37	
Regulatory Information	39	
Warranty	43	
Index	45	

Copyright © 2004 Elo TouchSystems Inc. All Rights Reserved.

No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system, or translated into any language or computer language, in any form or by any means, including, but not limited to, electronic, magnetic, optical, chemical, manual, or otherwise without prior written permission of Elo TouchSystems.

Disclaimer

The information in this document is subject to change without notice. Elo TouchSystems makes no representations or warranties with respect to the contents hereof, and specifically disclaims any implied warranties of merchantability or fitness for a particular purpose. Elo TouchSystems reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of Elo TouchSystems to notify any person of such revisions or changes.

Trademark Acknowledgments

IntelliTouch, SecureTouch, AccuTouch, Entuitive, and MonitorMouse are trademarks of Elo TouchSystems, Inc.

Other product names mentioned herein may be trademarks or registered trademarks of their respective companies. Elo TouchSystems claims no interest in trademarks other than its own.

INTRODUCTION

Congratulations on your purchase of an Elo TouchSystems Entuitive touchmonitor. Your new touchmonitor combines the reliable performance of Elo's touch technology with the latest advances in LCD display design. This combination of features creates a natural flow of information between a user and your touchmonitor.

Precautions

Follow all warnings, precautions and maintenance as recommended in this user's manual to maximize the life of your unit. See Appendix B for more information on touchmonitor safety.

About the Product

Your LCD Kiosk Touchmonitor is a 19" SXGA TFT color display with the following features:

- Direct analog RGB or Digital input
- 19.0" diagonal screen size
- 16.7 million displayable colors
- 1280 x 1024 resolution
- SXGA/ XGA/ SVGA/ VGA/VESA/ Mac compatible
- 30kHz~80 horizontal scan
- 56~75Hz refresh rate

- Auto adjustment capability
- High quality full screen re-scaling
- Multilingual OSD menus in 11 languages: English, Spanish, German, French, Italian, Swedish, Finnish, Danish, Dutch, Portuguese, and Japanese
- Serial or USB touch interface (USB requires Windows 98, 2000, Me and XP.)
- Patented touch technology of Elo TouchSystems
- VESA DDC 1/2B data communication
- VESA DPMS power saving
- Cable management device
- VESA flat panel monitor physical mounting interface (Both of 75 & 100mm)


For full Product Specifications refer to Appendix C.

INSTALLATION AND SETUP


This chapter discusses how to install your LCD touchmonitor and how to install Elo TouchSystems driver software.

Unpacking Your Touchmonitor

Check that the following 10 items are present and in good condition:



LCD Display




USB touchscreen cable


Serial touchscreen cable




Video cable



DVI-D video cable




OSD Remote




User Guide-on CD, Quick Install Guide and software CD



Adapter



European monitor power cable




Monitor power cable (US/Canada)


Use only an AD-4515L power adapter with this product.

Product Overview


Main Unit




Rear View



Bottom View



See Detail A




Detail A

Use only an AD-4515L power adapter with this product.

Attaching the L-Brackets

NOTE: You will need a screwdriver to attach the L-brackets.

Your kiosk touchmonitor comes with two mounting brackets (L-brackets) included in the accessory kit. There are four ways to mount your touchmonitor; horizontal, vertical, horizontal side mount, and vertical side mount. Please refer to “VESA Mount on Your Touchmonitor” on page 2-15 for VESA mounting information.



Panel Cut Outs



Mounting Options

The following applies to all mounting options:



- 1 All drawing centers are the center of the viewable area.
- 2 LCD panel cutout dimensions in the horizontal mount option applies to the vertical mount option.
- 3 If the kiosk material is wood:
 - 1 Ø4.5 holes through for M4 screws with nuts.
 - 2 If there are no through holes then screws for wood Ø4.
- 4 If the kiosk material is sheet metal, use concealed head threaded studs M4 with nuts.

NOTE: Dimensions are for non-touch, AccuTouch and IntelliTouch only. For SecureTouch add 4mm to each dimension.

Horizontal Mount




Vertical Mount




Horizontal Side Mount

HORIZONTAL SIDE MOUNT



Vertical Side Mount

VERTICAL SIDE MOUNT



Touch Interface Connection

Your touchmonitor comes with one of the following touchscreen connector cables: **Serial** (RS-232) cable *or* **USB** cable. (For Windows 98, 2000, Me and XP systems only.)


To set up this display, please refer to the following figures and procedures:

Serial or USB Connection

The following illustrations guide you step by step in connecting your touchmonitor using a serial cable connection.


CAUTION

Before connecting the cables to your touchmonitor and PC, be sure that the computer and the touchmonitor are turned off.




Use only an AD-4515L power adapter with this product.

STEP 1-Connecting the Video Cable




- Connect the 15-pin video cable (the ferrite bead end) or 24-pin DVI cable to the video port on your PC.
- Connect the other end of the video cable to the video connector on your touchmonitor.
- Secure the cable to your touchmonitor and PC by turning the screws on the connector clockwise.

STEP 2-Connecting the Serial/USB Touchscreen Cable




- Connect the female end of the serial (RS-232) or USB cable to the touchscreen port on the back of your PC.
- Connect the male end of the cable to the serial or USB touchscreen connector on your touchmonitor.
- Secure the cable to your touchmonitor and PC by turning the screws on the connector.
- Route the cable through the cable management clip.

Step 3-Connecting the OSD Remote Cable



- Connect the 6-pin remote OSD DIN cable to the black remote OSD port of the monitor.

STEP 4-Connecting the Power Cable



Depending on where you live, you will use either the European or US/Canadian power cable.

- Connect the female end of the power cable to the power port on the touchmonitor.
- Use only an AD-4515L power adapter with this product.

NOTE: To protect your equipment against risk of damage from electrical surges in the power line, plug the touchmonitor's power cord into a surge protector, and then connect the surge protector to a grounded AC electrical outlet.


Optimizing the LCD Display

To ensure the LCD display works well with your computer, configure the display mode of your graphic card to make it less than or equal to 1024 x 768 resolution, and make sure the timing of the display mode is compatible with the LCD display. Refer to Appendix A for more information about resolution. Compatible video modes for your touchmonitor are listed in Appendix C.

VESA Mount on Your Touchmonitor

Your touchmonitor conforms to the VESA Flat Panel Monitor Physical Mounting Interface (FPMPMI™) Standard which defines a physical mounting interface for flat panel monitors, and corresponding standards for flat panel monitor mounting devices, such as wall and table arms. The VESA mounting interface is located on the back of your touchmonitor and is shipped pre-connected to the base.

To use the VESA mount, unscrew the rear U bracket, then mount to either 75mm or 100mm VESA mount. Use M4x.7 machine screws. Do not penetrate the screw into the monitor more than 10mm.



NOTE: The above drawing displays the VESA mounting interface after the removal of the mounting cover and base.

VESA Mounting Interface

Your monitor has standard VESA mounting holes on the rear of the unit. The holes are spaced at 75mm and 100mm standard.

The following companies provide VESA mounting devices compatible with your touchmonitor:

Ergotron
800-888-8458
651-681-7600
www.ergotron.com

GCX
800-228-2555
707-773-1100
www.gcx.com

Innovative Office Products
800-524-2744
610-253-9554
www.innov-office-prod.com

MRI
800-688-2414
www.mediarecovery.com

Installing the Driver Software

Elo TouchSystems provides driver software that allows your touchmonitor to work with your computer. Drivers are located on the enclosed CD-ROM for the following operating systems:

- Windows XP
- Windows 2000
- Windows Me
- Windows 98
- Windows 95
- Windows NT 4.0

Additional drivers and driver information for other operating systems (including MS DOS, Windows 3.x, OS/2, Macintosh and Linux) are available on the Elo TouchSystems web site at www.elotouch.com.

Your Elo touchmonitor is plug-and-play compliant. Information on the video capabilities of your touchmonitor is sent to your video display adapter when Windows starts. If Windows detects your touchmonitor, follow the instructions on the screen to install a generic plug-and-play monitor.

Refer to the appropriate following section for driver installation instructions.

Installing the Serial Touch Driver

Installing the Serial Touch Driver for Windows XP, Windows 2000, Me, 95/98 and NT 4.0

NOTE: For Windows 2000 and NT 4.0 you must have administrator access rights to install the driver.

- 1** Insert the Elo CD-ROM in your computer's CD-ROM drive.
- 2** If the AutoStart feature for your CD-ROM drive is active, the system automatically detects the CD and starts the setup program.
- 3** Follow the directions on the screen to complete the driver setup for your version of Windows.
- 4** If the AutoStart feature is not active:
- 5** Click **Start > Run**.
- 6** Click the **Browse** button to locate the EloCd.exe program on the CD-ROM.
- 7** Click **Open**, then **OK** to run EloCd.exe.
- 8** Follow the directions on the screen to complete the driver setup for your version of Windows.

Installing the Serial Touch Driver for MS-DOS and Windows 3.1

You must have a DOS mouse driver (MOUSE.COM) installed for your mouse if you wish to continue using your mouse along with your touchmonitor in DOS.

To install Windows 3.x and MS-DOS from Windows 95/98, follow the directions below:

- 1 Insert the Elo CD-ROM in your computer's CD-ROM drive.
- 2 From DOS, type `d:\EloDos_W31` to change to the correct directory on the CD-ROM (your CD-ROM drive may be mapped to a different drive letter).
- 3 Type `install` and press **Enter** to start the installation.
- 4 Align the touchscreen.

You must have already completed Steps 1 and 2 before proceeding. Refer to Chapter 2 of the Elo DOS and Windows Driver Guide as necessary for additional installation information.

To run the INSTALL program:

- 1 Type `INSTALL` at the DOS prompt in the directory containing the driver install files.
- 2 `INSTALL` asks you to select the software to install. Then choose `d:\EloDos_W31` from the displayed list.
- 3 `INSTALL` also asks you for the paths to use during installation, or you may use its defaults. `INSTALL` creates directories as necessary, and warns you if they exist.

If you are updating your software, you may wish to specify the paths containing the earlier versions, and overwrite the obsolete files. All executable programs are upward compatible. For a list of differences from each previous version of the drivers, be sure to select "Differences from Previous Versions" during the installation process.

`INSTALL` updates your `AUTOEXEC.BAT` file with the drivers you select. `INSTALL` makes a copy of your original `AUTOEXEC.BAT` file, called `AUTOEXEC.OLD`. If you already have Elo driver commands in your `AUTOEXEC.BAT` file, they will be commented out.

When `INSTALL` is finished, it leaves a file called `GO.BAT` in the subdirectory you specified. `GO` loads the touchscreen driver, runs the calibration program `ELOCALIB`, and gives you some final instructions.

If you are using Windows 3.1, you will also calibrate the touchscreen within Windows 3.1 with the Touchscreen Control Panel.

Installing the USB Touch Driver

Installing the USB Touch Driver for Windows XP, Windows 2000, Me and 98

- 1 Insert the Elo CD-ROM in your computer's CD-ROM drive.

If Windows 98, Windows Me or Windows 2000 starts the Add New Hardware Wizard:

- 2 Choose **Next**. Select "Search for the best driver for your device (Recommended)" and choose **Next**.
- 3 When a list of search locations is displayed, place a checkmark on "Specify a location" and use **Browse** to select the \EloUSB directory on the Elo CD-ROM.
- 4 Choose **Next**. Once the Elo TouchSystems USB touchscreen driver has been detected, choose **Next** again.
- 5 You will see several files being copied. Insert your Windows 98 CD if prompted. Choose **Finish**.

If Windows 98, Windows Me or Windows 2000 does not start the Add New Hardware Wizard:

NOTE: For Windows 2000 you must have administrator access rights to install the driver.

- 1 Insert the Elo CD-ROM in your computer's CD-ROM drive.

If the AutoStart feature for your CD-ROM drive is active, the system automatically detects the CD and starts the setup program.

- 2 Follow the directions on the screen to complete the driver setup for your version of Windows.

If the AutoStart feature is not active:

- 1 Click **Start > Run**.
- 2 Click the **Browse** button to locate the EloCd.exe program on the CD-ROM.
- 3 Click **Open**, then **OK** to run EloCd.exe.
- 4 Follow the directions on the screen to complete the driver setup for your version of Windows.

About Touchmonitor Adjustments

Your touchmonitor will unlikely require adjustment. Variations in video output and application may require adjustments to your touchmonitor to optimize the quality of the display.

For best performance, your touchmonitor should be operating in native resolution, that is 1280 x 1024 at 60-75 Hz. Use the Display control panel in Windows to choose 1280 x 1024 resolution.

Operating in other resolutions will degrade video performance. For further information, please refer to Appendix A.


All adjustments you make to the controls are automatically memorized. This feature saves you from having to reset your choices every time you unplug or power your touchmonitor off and on. If there is a power failure your touchmonitor settings will not default to the factory specifications.

Using the On-Screen Display (OSD) Menus

All adjustments are made by using the on-screen display (OSD) menus. All menu items can be selected by using the buttons on the Remote OSD key.


NOTE: OSD menu default is enabled.

Remote OSD Buttons



	Control	Function
① MENU	Menu	Display/Exits the OSD menus.
② Up	Brightness/ Plus/Clockwise	1. Adjust brightness of the OSD. 2. Increase value of adjustment items 3. Select item clockwise.
③ Down	Volume/Down Toggle	1. Decreases the value of the adjustment items 2. Select item counter-clockwise.
④ AUTO/SEL	Enter Select item	1. Select- To select the adjustment items from the OSD menus. 2. Auto- To activate the “Auto Adjustment” function to obtain an optimum image.
⑤	Power Switch	Switches the power to your touchmonitor on/off.
	Enable/Disable	1. Press the Menu and Up buttons at the same time and hold for two seconds to enable/disable the OSD functions. The OSD menu default is enabled. 2. Press the Menu and Up buttons at the same time and hold for two seconds to enable/disable the Power Lock function.

OSD Menu Function



Function	Symbol	Process
Brightness		Controls the picture brightness.
Contrast		Controls the picture contrast.
Color Control		In this menu you can select one of the default color temperatures (5500°K, 6500°K, 9300°K). Press the OSD button Up or Down or set color values, individually using the "USER" option. To define the color values individually, select the "USER" option. You can switch between the setting options for R/G/B (red, green and blue foreground) using the OSD direction button. Select and specify the desired value by using the OSD button.
Position		Controls the horizontal and vertical position.
Clock Phase		Controls the horizontal image size. Controls the vertical and horizontal fine tuning.
Misc		
Language		Selection of the OSD menu language: English, Spanish, German, French, Italian, Swedish, Finish, Danish, Dutch, Portuguese, and Japanese.
Recall defaults		Recall factory settings of the image parameters.
Auto Adjust		Automatically selects the optional settings for image parameters (brightness, contrast, image position, phase, etc.).
Input Select		Selects the connection for the display: DSUB Analog.

TROUBLESHOOTING

If you are experiencing trouble with your touchmonitor, refer to the following table. If the problem persists, please contact your local dealer or our service center.

Solutions to Common Problems

Problem	Suggestion(s)
No image appears on screen.	<p>Check that all the I/O and power connectors are properly connected as described in Chapter 2.</p> <p>Make sure the pins of the connectors are not crooked or broken.</p> <p>Test power supply by trying different cables, a different wall outlet or plug another appliance into the outlet.</p> <p>Make certain the video cable is properly connected and that it is not damaged. Check for bent pins on the cable connectors.</p> <p>Ensure that your computer and video card are properly configured. (Consult video card documentation.)</p>
“Out of Range” display	<p>Check to see if the resolution of your computer is higher than that of the LCD display.</p> <p>Reconfigure the resolution of your computer to make it less than or equal to 1280 x 1024. See Appendix A for more information on resolution.</p>

Image has vertical flickering line bars.	Use "PHASE" to make an adjustment. Check and reconfigure the display mode of the vertical refresh rate of your graphic card to make it compatible with the LCD display.
Image is unstable and flickering	Use "CLOCK" to make an adjustment.
Image is scrolling	Make sure the VGA signal cable (or adapter) is well connected. Check and reconfigure the display mode of the vertical refresh rate of your graphic card to make it compatible with the LCD display.
Touch doesn't work	Make sure cable is securely attached at both ends.

APPENDIX



NATIVE RESOLUTION

The native resolution of a monitor is the resolution level at which the LCD panel is designed to perform best. For the Elo LCD touchmonitor, the native resolution is 1280 x 1024 for the SXGA-19 inch size. In almost all cases, screen images look best when viewed at their native resolution. You can lower the resolution setting of a monitor but not increase it.

The native resolution of an LCD is the actual number of pixels horizontally in the LCD by the number of pixels vertically in the LCD. LCD resolution is usually represented by the following symbols:

VGA	640x480
SVGA	800x600
XGA	1024x768
SXGA	1280x1024
UXGA	1600x1200

As an example, a SVGA resolution LCD panel has 800 pixels horizontally by 600 pixels vertically. Input video is also represented by the same terms. XGA input video has a format of 1024 pixels horizontally by 768 pixels vertically. When the input pixels contained in the video input format match the native resolution of the panel, there is a one to one correspondence of mapping of input video pixels to LCD pixels. As an example, the pixel in column 45 and row 26 of the input video is in column 45 and row 26 of the LCD. For the case when the input video is at a lower resolution than the native resolution of the LCD, the direct correspondence between the video pixels and the LCD pixels is lost. The LCD controller can compute the correspondence between video pixels and LCD pixels using algorithms contained on its controller. The accuracy of the algorithms determines the fidelity of conversion of video pixels to LCD pixels. Poor fidelity conversion can result in artifacts in the LCD displayed image such as varying width characters.

B

TOUCHMONITOR SAFETY

This manual contains information that is important for the proper setup and maintenance of your touchmonitor. Before setting up and powering on your new touchmonitor, read through this manual, especially Chapter 2 (Installation), and Chapter 3 (Operation).


- 1** To reduce the risk of electric shock, follow all safety notices and never open the touchmonitor case.
- 2** Turn off the product before cleaning
- 3** Your new touchmonitor is equipped with a 3-wire, grounding power cord. The power cord plug will only fit into a grounded outlet. Do not attempt to fit the plug into an outlet that has not been configured for this purpose. Do not use a damaged power cord. Use only the power cord that comes with your Elo TouchSystems Touchmonitor. Use of an unauthorized power cord may invalidate your warranty.
- 4** The slots located on the sides and top of the touchmonitor case are for ventilation. Do not block or insert anything inside the ventilation slots.
- 5** It is important that your touchmonitor remains dry. Do not pour liquid into or onto your touchmonitor. If your touchmonitor becomes wet do not attempt to repair it yourself.

Care and Handling of Your Touchmonitor

The following tips will help keep your Elo Entuitive touchmonitor functioning at the optimal level.

- To avoid risk of electric shock, do not disassemble the brick supply or display unit cabinet. The unit is not user serviceable. Remember to unplug the display unit from the power outlet before cleaning.
- Do not use alcohol (methyl, ethyl or isopropyl) or any strong dissolvent. Do not use thinner or benzene, abrasive cleaners or compressed air.
- To clean the display unit cabinet, use a cloth lightly dampened with a mild detergent.
- Avoid getting liquids inside your touchmonitor. If liquid does get inside, have a qualified service technician check it before you power it on again.
- Do not wipe the screen with a cloth or sponge that could scratch the surface.
- To clean the touchscreen, use window or glass cleaner. Put the cleaner on the rag and wipe the touchscreen. *Never* apply the cleaner directly on the touchscreen





TECHNICAL SPECIFICATIONS

Compatible Video Modes

Your Elo Entuitive touchmonitor is compatible with the following standard video modes:

Mode	Resolution	H. Frequency (kHz)	V. Frequency (Hz)
VGA	720 x 400	31,470	70
VGA	640 x 480	31,470	60
MAC	640 x 480	35,000	66
VESA	640 x 480	37,860	72
VESA	640 x 480	37,500	75
VESA	800 x 600	35,160	56
VESA	800 x 600	37,880	60
VESA	800 x 600	46,880	75
VESA	800 x 600	48,080	72
MAC	832 x 624	49,720	75
VESA	1024 x 768	48,360	60
VESA	1024 x 768	56,480	70
VESA	1024 x 768	60,020	75
SXGA	1280 x 1024	64,000	60
SXGA	1280 x 1024	80,000	75
SXGA	1152 x 864	67,500	75
SXGA	1280 x 960	60,000	60

19. LCD Touchmonitor (ET1947L-XXWC-1) Specifications

Display Type	19.0" diagonal Active matrix, TFT LCD
Useful Screen Area	Horizontal: 14.8" (376mm) Vertical: 11.9" (301mm)
Monitor Dimensions	Width: 17.1" (434mm) Height: 14.2" (361mm) Depth: 2.16" (54.7mm)
Optimal (native) Resolution	1280 x 1024 at 75Hz
Other supported resolutions	1152 x 864 at 60, 70, or 75 Hz 1024 x 768 at 60, 65, or 75 Hz 832 x 624 at 75 Hz 800 x 600 at 56, 60, 72, or 75Hz 720 x 400 at 70 Hz 640 x 480 at 60, 72, or 75 Hz
Colors	16.7 million with dithering
Brightness LCD panel	300 cd/m ²
Brightness LCD panel with touchscreen	276 cd/m ² typical
Response Time	Tr: 15 msec (typical) Tr: 10 msec (typical)
Viewing Angle	Horizontal (left/right): ±85 or 170° total (typical) at CR=10 Vertical (up/down): ±85 or 170° total (typical) at CR=10
Contrast Ratio	700:1 typical
Input Video Format	Analog (no proprietary video card needed); Digital Video Input
Input Video Signal Connector	DVI-D or mini D-Sub 15-pin
Input Frequency	Horizontal: 31-80 kHz Vertical: 56-75 Hz
Power Supply	External power supply, 100-240 VAC, 50-60 Hz Monitor input voltage: 12 V Current: 4.2 A max. Use ONLY an AD-4515 power adapter with this product.
Power Dissipation	40 W max.
Temperature	Operating: 0-45° Storage: -20°C to 60°C

Humidity	Operating: 20-80% Storage: 5-95% non condensing
Weight	Actual: 20 lb. (9.1 kg) Shipping: 29 lb. (13.2 kg)
Touch Interface	Serial, USB
Surface Treatment	Anti-glare
Agency Approvals	UL/cUL, FCC, IC, CE, TÜV-GS, VCCI, C-Tick
Other Features	100 or 75 mm VESA mounting Rear mount through bezel or with brackets; panel mount option User controls: <ul style="list-style-type: none"> • Remote (1.8mm cable) OSD: Auto/Sel, up, down • OSD: contrast, brightness, H/V position, color, temperature, clock, phase, language

IntelliTouch Touchmonitor Specifications

Mechanical

Positional Accuracy	Standard deviation of error is less than 0.080 in. (2.03 mm). Equates to less than $\pm 1\%$.
Touchpoint Density	More than 100,000 touchpoints/in ² (15,500 touchpoints/cm ²).
Touch Activation Force	Typically less than 3 ounces (85 grams).
Surface Durability	Surface durability is that of glass, Mohs' hardness rating of 7.
Expected Life Performance	No known wear-out mechanism, as there are no layers, coatings, or moving parts. IntelliTouch technology has been operationally tested to more than 50 million touches in one location without failure, using a stylus similar to a finger.
Sealing	Unit is sealed to protect against splashed liquids, dirt, and dust.

Optical

Light Transmission (per ASTM D1003)	90%
Visual Resolution	All measurements made using USAF 1951 Resolution Chart, under 30X magnification, with test unit located approximately 1.5 in (38 mm) from surface of resolution chart. Clear surface: Excellent, with no noticeable degradation. Antiglare surface: 6:1 minimum.
Gloss (per ASTM D2457 using a 60-degree gloss meter)	Antiglare surface: Curved: 60 ± 20 gloss units or 75 ± 15 gloss units.

Environmental

Chemical Resistance

The active area of the touchscreen is resistant to all chemicals that do not affect glass, such as:

- Acetone
- Toluene
- Methyl ethyl ketone
- Isopropyl alcohol
- Methyl alcohol
- Ethyl acetate
- Ammonia-based glass cleaners
- Gasoline
- Kerosene
- Vinegar

**Electrostatic Protection
(per EN 61 000-4-2, 1995)**

Meets Level 4 (15 kV air/8 kV contact discharges).

AccuTouch Touchmonitor Specifications

Mechanical

Construction

Top: Polyester with outside hard-surface coating with clear or antiglare finish.

Inside: Transparent conductive coating.

Bottom: Glass substrate with uniform resistive coating. Top and bottom layers separated by Elo-patented separator dots.

Positional Accuracy

Standard deviation of error is less than 0.080 in. (2.03 mm). This equates to less than $\pm 1\%$.

Touchpoint Density

More than 100,000 touchpoints/in² (15,500 touchpoints/cm²).

Touch Activation Force

Typically less than 4 ounces (113 grams).

Surface Durability

Meets Taber Abrasion Test (ASTM D1044), CS-10F wheel, 500 g.
Meets pencil hardness 3H.

Expected Life Performance

AccuTouch technology has been operationally tested to greater than 35 million touches in one location without failure, using a stylus similar to a finger.

Optical

Light Transmission (per ASTM D1003)

Typically 75% at 550-nm wavelength (visible light spectrum).

Visual Resolution

All measurements made using USAF 1951 Resolution Chart, under 30 X magnification, with test unit located approximately 1.5 in. (38 mm) from surface of resolution chart.

Antiglare surface: 6:1 minimum.

Haze (per ASTM D1003)


Antiglare surface: Less than 15%.

Gloss (per ASTM D2457)

Antiglare surface: 90 ± 20 gloss units tested on a hard-coated front surface.


19" LCD Touchmonitor (ET1947L-XXWA-1) Dimensions

Front Dimensions



*Noted dimensions are for non-touch, AccuTouch, and IntelliTouch only. For SecureTouch add 4mm to dimensions.

Rear Dimensions



REGULATORY INFORMATION

I. Electrical Safety Information:

A) Compliance is required with respect to the voltage, frequency, and current requirements indicated on the manufacturer's label. Connection to a different power source than those specified herein will likely result in improper operation, damage to the equipment or pose a fire hazard if the limitations are not followed.

B) There are no operator serviceable parts inside this equipment. There are hazardous voltages generated by this equipment which constitute a safety hazard. Service should be provided only by a qualified service technician.

C) This equipment is provided with a detachable power cord which has an integral safety ground wire intended for connection to a grounded safety outlet.

1) Do not substitute the cord with other than the provided approved type. Under no circumstances use an adapter plug to connect to a 2-wire outlet as this will defeat the continuity of the grounding wire.

2) The equipment requires the use of the ground wire as a part of the safety certification, modification or misuse can provide a shock hazard that can result in serious injury or death.

3) Contact a qualified electrician or the manufacturer if there are questions about the installation prior to connecting the equipment to mains power.

II. Emissions and Immunity Information

A) Notice to Users in the United States: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

B) Notice to Users in Canada: This equipment complies with the Class B limits for radio noise emissions from digital apparatus as established by the Radio Interference Regulations of Industrie Canada.

C) Notice to Users in the European Union: Use only the provided power cords and interconnecting cabling provided with the equipment. Substitution of provided cords and cabling may compromise electrical safety or CE Mark Certification for emissions or immunity as required by the following standards:

This Information Technology Equipment (ITE) is required to have a CE Mark on the manufacturer's label which means that the equipment has been tested to the following Directives and Standards:

This equipment has been tested to the requirements for the CE Mark as required by EMC Directive 89/336/EEC indicated in European Standard EN 55 022 Class B and the Low Voltage Directive 73/23/EEC as indicated in European Standard EN 60 950.

D) General Information to all Users: This equipment generates, uses and can radiate radio frequency energy. If not installed and used according to this manual the equipment may cause interference with radio and television communications. There is, however, no guarantee that interference will not occur in any particular installation due to site-specific factors.


1) In order to meet emission and immunity requirements, the user must observe the following:

- a) Use only the provided I/O cables to connect this digital device with any computer.
- b) To ensure compliance, use only the provided manufacturer's approved line cord.
- c) The user is cautioned that changes or modifications to the equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

2) If this equipment appears to cause interference with radio or television reception, or any other device:

- a) Verify as an emission source by turning the equipment off and on.
- b) If you determine that this equipment is causing the interference, try to correct the interference by using one or more of the following measures:
 - i) Move the digital device away from the affected receiver.
 - ii) Reposition (turn) the digital device with respect to the affected receiver.
 - iii) Reorient the affected receiver's antenna.
 - iv) Plug the digital device into a different AC outlet so the digital device and the receiver are on different branch circuits.
 - v) Disconnect and remove any I/O cables that the digital device does not use. (Unterminated I/O cables are a potential source of high RF emission levels.)
 - vi) Plug the digital device into only a grounded outlet receptacle. Do not use AC adapter plugs. (Removing or cutting the line cord ground may increase RF emission levels and may also present a lethal shock hazard to the user.)

If you need additional help, consult your dealer, manufacturer, or an experienced radio or television technician.



N10051

WARRANTY

Except as otherwise stated herein or in an order acknowledgment delivered to Buyer, Seller warrants to Buyer that the Product shall be free of defects in materials and workmanship. The warranty for the touchmonitors and components of the product is 3 years.

Seller makes no warranty regarding the model life of components. Seller's suppliers may at any time and from time to time make changes in the components delivered as Products or components.

Buyer shall notify Seller in writing promptly (and in no case later than thirty (30) days after discovery) of the failure of any Product to conform to the warranty set forth above; shall describe in commercially reasonable detail in such notice the symptoms associated with such failure; and shall provide to Seller the opportunity to inspect such Products as installed, if possible. The notice must be received by Seller during the Warranty Period for such product, unless otherwise directed in writing by the Seller. Within thirty (30) days after submitting such notice, Buyer shall package the allegedly defective Product in its original shipping carton(s) or a functional equivalent and shall ship to Seller at Buyer's expense and risk.

Within a reasonable time after receipt of the allegedly defective Product and verification by Seller that the Product fails to meet the warranty set forth above, Seller shall correct such failure by, at Seller's options, either (i) modifying or repairing the Product or (ii) replacing the Product. Such modification, repair, or replacement and the return shipment of the Product with minimum insurance to Buyer shall be at Seller's expense. Buyer shall bear the risk of loss or damage in transit, and may insure the Product. Buyer shall reimburse Seller for transportation cost incurred for Product returned but not found by Seller to be defective. Modification or repair, of Products may, at Seller's option, take place either at Seller's facilities or at Buyer's premises. If Seller is unable to modify, repair, or replace a Product to conform to the warranty set forth above, then Seller shall, at Seller's option, either refund to Buyer or credit to Buyer's account the purchase price of the Product less depreciation calculated on a straight-line basis over Seller's stated Warranty Period.

THESE REMEDIES SHALL BE THE BUYER'S EXCLUSIVE REMEDIES FOR BREACH OF WARRANTY. EXCEPT FOR THE EXPRESS WARRANTY SET FORTH ABOVE, SELLER GRANTS NO OTHER WARRANTIES, EXPRESS OR IMPLIED BY STATUTE OR OTHERWISE, REGARDING THE PRODUCTS, THEIR FITNESS FOR ANY PURPOSE, THEIR QUALITY, THEIR MERCHANTABILITY, THEIR NONINFRINGEMENT, OR OTHERWISE. NO EMPLOYEE OF SELLER OR ANY OTHER PARTY IS AUTHORIZED TO MAKE ANY WARRANTY FOR THE GOODS OTHER THAN THE WARRANTY SET FORTH HEREIN. SELLER'S LIABILITY UNDER THE WARRANTY SHALL BE LIMITED TO A REFUND OF THE PURCHASE PRICE OF THE PRODUCT. IN NO EVENT SHALL SELLER BE LIABLE FOR THE COST OF PROCUREMENT OR INSTALLATION OF SUBSTITUTE GOODS BY BUYER OR FOR ANY SPECIAL, CONSEQUENTIAL, INDIRECT, OR INCIDENTAL DAMAGES.

Buyer assumes the risk and agrees to indemnify Seller against and hold Seller harmless from all liability relating to (i) assessing the suitability for Buyer's intended use of the Products and of any system design or drawing and (ii) determining the compliance of Buyer's use of the Products with applicable laws, regulations, codes, and standards. Buyer retains and accepts full responsibility for all warranty and other claims relating to or arising from Buyer's products, which include or incorporate Products or components manufactured or supplied by Seller. Buyer is solely responsible for any and all representations and warranties regarding the Products made or authorized by Buyer. Buyer will indemnify Seller and hold Seller harmless from any liability, claims, loss, cost, or expenses (including reasonable attorney's fees) attributable to Buyer's products or representations or warranties concerning same.

INDEX

Numerics

- 19" LCD Touchmonitor (ET1947L-XXWA-1)
 - Dimensions, 36
- 19" LCD Touchmonitor (ET1947L-XXWC-1)
 - Specifications, 32

A

- About the Product, 1
- About Touchmonitor Adjustments, 21
- AccuTouch Touchmonitor Specifications, 35
- Agency Approvals, 33
- Attaching the L-Brackets, 5

B

- Bottom View, 5
- Brightness LCD panel, 32
- Brightness LCD panel with touchscreen, 32

C

- Care and Handling of Your Touchmonitor, 30
- Chemical Resistance, IntelliTouch, 34
- Cleaning Your Touchmonitor, 30
- Colors, 32
- Compatible Video Modes, 31
- Construction, AccuTouch, 35
- Contrast Ratio, 32

D

- Display Type, 32

E

- Electrical Safety Information, 39
- Electrostatic Protection, IntelliTouch, 34
- Emissions and Immunity Information, 39
- Enable/Disable, 22
- Environmental, 34
- Expected Life Performance, AccuTouch, 35
- Expected Life Performance, IntelliTouch, 33

F

- Front Dimensions, 36

G

- Gloss, AccuTouch, 35
- Gloss, IntelliTouch, 33

H

- Haze, AccuTouch, 35
- Horizontal Mount, 7
- Horizontal Side Mount, 9
- Humidity, 33

I

- Image problem, 25
- Image, scrolling, 26
- Image, unstable, 26
- Image, vertical flickering, 26
- Input Frequency, 32
- Input Video Format, 32
- Input Video Signal Connector, 32
- Installation and Setup, 3
- Installing the Driver Software, 17
- Installing the Serial Touch Driver, 18
- Installing the Serial Touch Driver for MS-DOS and Windows 3.1, 19
- Installing the Serial Touch Driver for Windows XP, Windows 2000, Me, 95/98 and NT 4.0, 18
- Installing the USB Touch Driver, 20
- Installing the USB Touch Driver for Windows XP, Windows 2000, Me and 98, 20
- IntelliTouch Touchmonitor Specifications, 33
- Introduction, 1

L

- Light Transmission, AccuTouch, 35
- Light Transmission, IntelliTouch, 33

M

- Main Unit, 4
- Mechanical, AccuTouch, 35
- Mechanical, IntelliTouch, 33
- Menu, 22
- Minus Counter-clockwise, 22
- Monitor Dimensions, 32
- Mounting Options, 6

N

- Native Resolution, 27

O

- Operation, 21
- Optical, AccuTouch, 35

- Optical, IntelliTouch, 33
- Optimal (native) Resolution, 32
- Optimizing the LCD Display, 15
- OSD Menu Function, 23
- Other Features, 33
- Other supported resolutions, 32
- Out of Range display, 25

P

- Panel Cut Outs, 6
- Positional Accuracy, AccuTouch, 35
- Positional Accuracy, IntelliTouch, 33
- Power Dissipation, 32
- Power Supply, 32
- Power Switch, 22
- Precautions, 1
- Product Overview, 4

R

- Rear Dimensions, 37
- Rear View, 4
- Regulatory Information, 39
- Remote OSD Buttons, 22
- Response Time, 32

S

- Sealing, IntelliTouch, 33
- Serial or USB Connection, 10
- Solutions to Common Problems, 25
- STEP 1-Connecting the Video Cable, 11
- STEP 2-Connecting the Serial/USB Touchscreen Cable, 12
- Step 3-Connecting the OSD Remote Cable, 13
- STEP 4-Connecting the Power Cable, 14
- Surface Durability, AccuTouch, 35
- Surface Durability, IntelliTouch, 33
- Surface Treatment, 33
- SVGA, 27
- SXGA, 27

T

- Technical Specifications, 31
- Temperature, operating, 32
- Temperature, storage, 32
- Touch Activation Force, AccuTouch, 35
- Touch Activation Force, IntelliTouch, 33
- Touch Interface, 33
- Touch Interface Connection, 10
- Touch not working, 26
- Touchmonitor Safety, 29
- Touchpoint Density, AccuTouch, 35
- Touchpoint Density, IntelliTouch, 33
- Troubleshooting, 25

U

- Unpacking Your Touchmonitor, 3
- Useful Screen Area, 32
- Using the On-Screen Display (OSD) Menus, 21
- UXGA, 27

V

- Vertical Mount, 8
- Vertical Side Mount, 9
- VESA Mount on Your Touchmonitor, 15
- VGA, 27
- Viewing Angle, 32
- Visual Resolution, AccuTouch, 35
- Visual Resolution, IntelliTouch, 33
- Volume, 22

W

- Warranty, 43
- Weight, 33

X

- XGA, 27

Check out Elo's Web site!

www.elotouch.com

Get the latest...

- **Product information**

 - **Specifications**

 - **News on upcoming events**

 - **Press releases**

 - **Software drivers**
-

Getting in Touch with Elo

To find out more about Elo's extensive range of touch solutions, visit our Web site at www.elotouch.com or simply call the office nearest you:

USA & Headquarters

Elo TouchSystems, Inc.
6500 Kaiser Drive
Fremont, CA 94555-3612

(800) ELO-TOUCH (800-356-8882)
Tel: 510-739-6016
Fax: 510-790-0827
elo@elotouch.com

Germany

Elo TouchSystems GmbH & Co. KG
Hedgrafen 6
D-65527 Odenbach
Germany

Tel: +49 (89) 80822-0
Fax: +49 (89) 80822-100
elo@elotouch.com

Belgium

Elo TouchSystems
Diestsesteenweg 682
B-3010 Kessel-Lo
Belgium

Tel: +32 (18) 35-2100
Fax: +32 (18) 35-2101
elotouch@elotouch.com

Japan

Touch Panel Systems K.K.
Sun Hamada Bldg. 2F
3-19-20 Shin-Yokohama
Kohoku-ku, Yokohama
Kanagawa 222-0322
Japan

Tel: +81 (48) 428-2781
Fax: +81 (48) 428-2180
www.tps.co.jp

tyco
Electronics

