

COM Port Installation Guidelines for Elo TouchSystems D-Series AiO Touchcomputer Serial Ports


May 2010



D-Series COM Port Assignments

- If the unit is purchased WITH an Operating System pre-installed by Elo TouchSystems, the default configuration of the COM ports is as shown below.
- If the unit is purchased WITHOUT a pre-installed Operating System (“No-OS”), then see the next page for instructions on how to install the COM ports correctly.

COM 3	Reserved for Cash Drawer
COM 4	USB to Serial Port
COM 5	USB to Serial Port
COM 6	USB to Serial Port
COM 7	USB to Serial Port



Guidelines For Installing COM Ports on No-OS Systems

- The purpose of this installation guide is to instruct customers purchasing a D-Series “No Operating System” unit on how to install the COM ports.
- When installing the Microsoft™ Windows operating system on multiple D-Series AiO touchcomputer systems, make sure to install the drivers for each of the Dual RS-232 and USB-to-Cash Drawer ports in the SAME EXACT ORDER each time.
- It is CRITICAL that the ports are installed and peripherals are plugged in the same order due to Windows assigning the next available COM port each time when the driver is installed.
- If multiple systems are to be configured to function exactly the same, the same installation order should be followed to have consistent COM ports assigned.

Device Manager

- See below for a screenshot of the Device Manager inside of Microsoft Windows XP as an example.

