

Replace the side door.



Turn on the touchcomputer.

## Included Items:

- · 80GB SATA hard drive
- · Four screws to mount hard drive
- Four grommets



## **Quick Installation Guide**

## Installing a Secondary Hard Drive for the 15D1 Touchcomputer

Caution:

Before installing the hard drive, make sure that the touchcomputer is powered off.











North America Elo TouchSystem 301 Constitution Drive, Menlo Park, CA 94025 Elo Technical Support
Online self-help:
www.elotouch.com/go/websupport
Technical Support contacts in your region:

Tel +32 (0)16 35 21 00 Fax +32 (0)16 35 21 01 elosales@elotouch.com

Asia-Pacific
11 00 Tel +81 (45) 478-2161
21 01 Fax +81 (45) 478-2180
h.com www.tps.co.ip

acific Latin America
(45) 478-2161 Tel 1-305-428-5210
1 (45) 478-2180 Fax 1-305-717-4909
s.co.ip www.elotouch.com.a











Turn off the power to the touchcomputer.




Remove the side door, as shown.



Remove the front door.



Remove the 2 screws and pull out the hard drive door.



Push in the 4 grommets.

Secure the drive with 4 screws.



Add the power and data cable.



Replace the hard drive door and the 2 screws.



**PPP** Replace the front door.